



## As New Quality

### The *Exatec ATM* renewing process detailed Step by Step

1. First check to compare if the reference is the right one regarding the product to renew
2. Creation of a single label per module, including part number, description, serial number & barcode
3. Barcode recording of the item and the involved technician in the database
4. Visual check of the product
5. Dismantling of all sub-parts
6. Cleaning of all mechanical parts in a ultrasonic treatment cleaner
7. Rinsing
8. Drying
9. Re-Assembling with replacement of all consumables, gears, belts, rollers...
10. Recording in our database of all consumables used during the process
11. Visual check of the re-assembled module
12. Connection on a dedicated bench test
13. Trial of x loops as defined for each model
14. Recording of the result with final validation
15. Dedicated package with additional label outside
16. Storage or shipment